



AD TACK FORCE FIBRA WALL

HIGH-STRENGTH ADHESIVE WITH FIBRES

Water dispersed fibre adhesive for gluing floors and coverings in homogeneous PVC, LVT, wall-to-wall carpeting and needlepunched carpeting, floors with foam rubber backing, jute and linoleum canvas.

TECHNICAL CHARACTERISTICS:

- Helps to maintain the dimensional stability of LVT
- **Odourless**
- Solvent-free
- Monocomponent acrylic
- High adhesive strength
- Strong initial adhesion
- For indoor use only
- Suitable for absorbent surfaces

WHERE IT CAN BE APPLIED:

- Absorbent walls
- Traditional concrete screeds
- Anhydrite screeds (calcium sulphate)
- Sub-floors and walls with underfloor heating or cooling systems

DO NOT USE:

- For laying steps, skirting boards or rubber coatings
- On non-absorbent flooring
- Concrete screeds with residual moisture content higher than applicable standards
- Screeds not protected by an appropriate vapour barrier

SPECIFIC CHARACTERISTICS (normal conditions):

Appearance:	Thixotropic paste
Colour	lvory
Brookfield viscosity at 20°C (mPa*s):	30,000 - 45,000
Specific weight (kg/l):	1.2 - 1.4
Yield: (g/m²):	
Trowel n° 2	250 - 300
Trowel n° 3	350 - 400
Trowel n° 4	400 - 500
Working life (minutes):	30 – 40
Final setting time (hours):	24 - 48
Usage temperature (°C):	+15 - +30
Application/Equipment:	Trowel
Equipment cleaning:	Water, before the product sets
Product removal:	Water, before the product sets
Storage (months): at a maximum temperature of +5°C	12
Disposal information:	Dispose of in compliance with the local and national regulations in force
Packaging:	12 kg
Recommendations for use:	Not suitable for outdoor use Do not bond on non-absorbent flooring Frost sensitive Always use suitable personal protective equipment Always consult the technical and safety information sheets

CONTINUE



ADHESIVES FOR TEXTILE AND RESILIENT FLOORING



AD TACK FORCE FIBRA WALL

SURFACE PREPARATION:

Always use suitable tools to check the moisture content in the sub-floor. The sub-floor to be treated must be compact, dry, free from loose parts and compliant with DIN 18356.

Before application, make sure that there is an adequate vapour barrier in place. Always use suitable tools to check the moisture content in the sub-floor. The moisture content in the sub-floor must be measured in depth (approx. 2-3 cm) using a carbide moisture tester. Do not apply on screeds that are not protected from possible rising damp (always ensure there is an appropriate vapour barrier between the screed and flooring). Lean or dusty concrete-based sub-floors should be consolidated with our K31 or PAVI-CRYL PRIMERS, which help the adhesive to bond perfectly to the surface (see the technical data sheet) and flattened using a self-leveller, such as our PAVILAST R. Do not use in areas without doors or closing devices. Do not use if the walls and ceilings in the room are not completely dry. Apply at least 2-3 mm of leveller or concrete skim-coat to non-absorbent sub-floors or walls.

APPLICATION:

Before gluing, always check the moisture content of the screed, which should be <2% (<0.5% anhydrite [calcium sulphate]). Ambient temperature between 15°C and 30°C, relative humidity no greater than 75%.

Floorings and coverings must be removed from their packaging several hours before being laid to give them time to acclimatise. Let the product reach room temperature and mix it before use. Use only a suitable notched trowel to spread the adhesive on the sub-floor. During the laying phase, constantly check that the adhesive has been transferred onto the back of the materials to be bonded.

Apply the covering by applying pressure evenly over the entire surface in order to force out any air bubbles. Clean up any adhesive spills immediately with a damp cloth.

Always use suitable personal protective equipment. Always consult the technical and safety data sheet for the product.

HAZARD PICTOGRAMS:

-- -- --