



ADHESIVES FOR WOOD FLOORS



PELPREN RR

BICOMPONENT POLYURETHANE ADHESIVE FOR SMALL QUICK REPAIRS

Two-component polyurethane adhesives for the rapid adhesion of flooring or wood elements on concrete subfloors or non-absorbent flooring.

TECHNICAL CHARACTERISTICS:

- Bicomponent
- Suitable for quick repairs or fitting wooden elements (e.g. stairs)
- Excellent adhesive power
- Water and solvent-free

WHERE IT CAN BE APPLIED:

- To repair wood panels
- To lay wooden elements
- To install steps, staircases, wooden platforms etc.

DO NOT USE:

- On oily surfaces
- On surfaces with loose material or not perfectly clean

SPECIFIC CHARACTERISTICS (normal conditions):

Colour:	Thick paste - comp. A Brown liquid - comp. B
Application temperature (°C):	+10 to 30
Application time (min):	5 - 15
Final hardening (hours):	1 - 2
Application/Equipment:	Toothed spatula
Equipment cleaning:	GR7, before the product sets
Product removal:	GR7, before the product sets
Product removal:	12
Disposal information	Dispose of in compliance with the local and national regulations in force
Packs	1-kg packs (A+B)
Usage limitations:	Apply on clean surfaces free of loose material. Do not let the product come into contact with varnished surfaces.

PREPARING THE SUBSTRATE

Make sure the surface is clean and free of oil, wax and loose material. Any dust residue, loose fragments or residue of incompatible products must be removed. In case of application on non-porous surfaces abrade the surface with sandpaper. When in doubt, it is advisable to test the product on a small area. Concrete powdery screeds or screeds with moisture must be treated beforehand with our primers to optimise adhesion of the product.

APPLICATION

Pour component B into the container of component A and mix thoroughly until a homogeneous, uniform paste is obtained. This paste must be spread on the least porous surface and applied evenly with a toothed spatula. The amount to apply will vary depending on the base to be glued. Carefully press the materials to be fixed onto the surface and, where necessary, use wedges or adhesive tape during the initial hardening phase of the product.

Always use adequate individual protection devices. Always consult the data and safety sheet of the product.